SMASH REPAIR GUIDE

JRA Parts

ROVER QUINTET



Key	Description		Part #	Model
1	**Bonnet**		R06630-693-010ZZ	
	Hinge	RH	R63410.693.310ZZ	
		LH	R63460-693-300ZZ	
	Lock		R63510-SA0-010	
2	**Grille**		R62301-693-010	
	Mould upper		R62320-693-000	
	Lower		R62302-693-010	
3	**Front b/bar**		R62510-693-010	
	End	RH	R62525-693-000	
		LH	R62526-693-000	
	Brk eh		R62530-693-010ZZ	
		LH	R62530-693-010ZZ	
4	**Front apron**		R60851-693-670ZZ	
5	**Front guard**	RH	R61110-693-621ZZ	
		LH	R61160-693-621ZZ	
	Skirt inner	RH	R60510-693-671ZZ	
		LH	R60581-693-671ZZ	
6	**Head lamp assembly**	RH	R33100-693-601	
		LH	R33150-693-601	
	Unit	RH	R33111-693-601	

Continued

Key	Description		Part #	Model
		LH	R33161-693-601	
7	**Door shell front**	RH	R75110-693-653ZZ	
		LH	R75150-693-652ZZ	
	Skin	RH	R75111-693-600ZZ	
		LH	R75151-693-600ZZ	
	Hinge upper		R75710-693-003ZZ	
	Lower		R75720-693-003ZZ	
8	**Handle door front outer**	RH	R75611-693-003	
		LH	R75621-693-003	
	Door striker		R75555-692-003	
	Door latch	RH	R75410-693-043	
		LH	R75450-693-043	
	Barrel & key		R75585-693-651	
9	**Door glass front**	RH	R75351-693-600	
		LH	R75361-693-600	
	Regulator front	RH	R75310-693-952	
		LH	R75320-693-952	
10	**Moulding protector guard**	RH	R75811-693-920	
		LH	R75816-693-920	
	Door front	RH	R75812-693-920	
		LH	R75817-693-920	
11	**Moulding protector door**	RH	R75813-693-920	
		LH	R75818-693-920	
	Guard rear	RH	R75814-693-920	
		LH	R75819-693-920	
12	**Waist mould door front**	RH	R75800-693-600	
		LH	R75805-693-600	
13	**Waist mould door rear**	RH	R76800-693-003	
		LH	R76805-693-003	
14	**Mirror door**	RH	R88150-693-751	
		LH	R88155-693-751	
15	**Door assembly rear**	RH	R76110-693-651ZZ	
		LH	R76150-693-651ZZ	
	Skin	RH	R76111-693-600ZZ	
		LH	R76151-693-600ZZ	
	Door hinge upper		R76710-693-003ZZ	
	Lower		R76720-693-003ZZ	

Continued

Key	Description		Part #	Model
16	**Handle door rear outer**	RH	R75611-693-003	
		LH	R75621-693-003	
	Door striker		R75555-692-003	
	Door lock rear	RH	R76410-693-033	
		LH	R76450-693-033	
17	**Door glass rear**	RH	R76351-693-000	
		LH	R76361-693-000	
	Door regulator	RH	R76310-693-952	
		LH	R76320-693-952	
18	**Rear 1/4 panel**	RH	R04732-693-610ZZ	
		LH	R04742-693-610ZZ	
	Lid petrol flap		R70490-693-000ZZ	
19	**Tail gate**		R04850-693-760ZZ	
	Struts		R85270-693-000	
	Lock		R83300-693-023	
20	**Tail lamp**	RH	R33500-693-661	
		LH	R33550-693-661	
	NO. plate lamp		R34100-SA5-631	
21	**Rear b/bar**		R84110-693-632	
	End	RH	R84117-693-010	
		LH	R84118-693-010	
	Brk	RH	R84126-693-010ZZ	
		LH	R84128-693-010ZZ	
22	**Panel assembly rear**		R80310-693-750ZZ	
23	**Panel roof**		R70110-693-300ZZ	
			R70110-693-920ZZ	SUN ROOF

ROVER 825



Key	Description		Part #	Model
1	**Bonnet**		CLP2722	
	Hinge	RH	DCP5790	
		LH	DCP5791	
	Striker		CLP6517	
	Strut		EDP1045	
2	**Grille**		DCP6911NN	WHITE
			DCP6911JW	AZURE BLUE
			DCP6911CE	TARGA RED
			DCP6911CP	OPORTO RED
			DCP6911GF	GOLD
			DCP6911ME	SILVER LEAF
3	**Front bar**		CLP4832	
	Brk	RH	DCP6023	
		LH	DCP6024	
4	**Front guard**	RH	CLP1568	
		LH	CLP1569	
	Skirt inner	RH	DEP2096	
		LH	DEP2097	
5	**Head lamp assembly**	RH	GLU676	
		LH	GLU675	
	Globe		JLM9598	

Continued

Key	Description		Part #	Model
6	**Flasher lamp assembly**	RH	CLP8236	
		LH	CLP8235	
	Flasher lamp side		AAU2592	
7	**Door shell front**	RH	DEP2178	
		LH	DEP2179	
	Skin	RH	DEP1104	
		LH	DEP1105	
	Door hinge front upper	RH	EDP1000	
		LH	EDP1001	
	Lower	RH	EDP1002	
		LH	EDP1003	
8	**Handle door front**	RH	CLP5422NN	WHITE
			CLP5422JW	AZURE BLUE
			CLP5422CF	TARGA RED
			CLP5422CP	OPORTO RED
			CLP5422GF	GOLD
			CLP5422ME	SILVER LEAF
		LH	CLP5423NN	WHITE
			CLP5423JW	AZURE BLUE
			CLP5423CF	TARGA RED
			CLP5423CP	OPORTO RED
			CLP5423GF	GOLD
			CLP5423ME	SILVER LEAF
	Door lock front	RH	EDP1048	
		LH	EDP1049	
	Door striker		DBP1326	
	Barrel & key	RH	CLP5426H	
		LH	CLP5427H	
9	**Door glass front**	RH	CLP5306	
		LH	CLP5307	
	Regulator glass front	RH	CLP6598	
		LH	CLP6599	
10	**Moulding protector guard**	RH	CLP5020	
		LH	CLP5021	
	Door front	RH	CLP5024	
		LH	CLP5025	
11	**Moulding protector door rear**	RH	CLP5028	
		LH	CLP5029	
	Guard rear	RH	CLP5032	
		LH	CLP5033	
	Insert rubbing strip guard	RH	CLP5030	
		LH	CLP5031	
	Door front	RH	CLP5017	
		LH	CLP5017	
	Door rear	RH	CLP5034	
		LH	CLP5035	

Continued

Key	Description		Part #	Model
13	**Waist mould**			
	Door front	RH	DCP5706	
		LH	DCP5707	
	Door rear	RH	EDP6128	
		LH	EDP6129	
14	**Door mirror**	RH	CLP6710	LESS MEMORY
		LH	CLP6713	
		RH	CLP6714	WITH MEMORY
		LH	CLP6717	
15	**Door rear**	RH	DEP2180	
		LH	DEP2181	
	Door skin	RH	DEP1106	
		LH	DEP1107	
	Door hinge upper	RH	EDP1004	
		LH	EDP1005	
	Lower	RH	EDP1006	
		LH	EDP1007	
16	**Handle door outer rear**	RH	CLP4926NN	WHITE
			CLP4926JW	AZURE BLUE
			CLP4926CE	TARGA RED
			CLP4926CP	OPORTO RED
			CLP4926GF	GOLD
			CLP4926ME	SILVER LEAF
		LH	CLP4927NN	WHITE
			CLP4927JW	AZURE BLUE
			CLP4927CE	TARGA RED
			CLP4927CP	OPORTO RED
			CLP4927GF	GOLD
			CLP4927ME	SILVER LEAF
	Door striker		DBP1326	
	Door lock rear	RH	CLP5428	
		LH	CLP5429	
17	**Door glass rear**	RH	CLP5312	
		LH	CLP5313	
	Regulator	RH	CLP6602	
		LH	CLP6603	
18	**Rear 1/4 panel**	RH	DEP2122	
		LH	DEP2123	
19	**Boot lid**		CLP1582	
	Hinge	RH	CLP5444	
		LH	CLP5445	
	Latch		CLP6508	
	Striker		CLP6458	

Continued

Key	Description		Part #	Model
20	**Tail lamp**	RH LH	BAU5836 BAU5837	
	NO. plate light		CLP8082	
21	**Rear b/bar**		CLP4841	
22	**Panel assembly rear**		DEP2113	
23	**Roof panel**		CLP1553 DEP2066	SUN ROOF

ROVER SD1



Key	Description		SD1	SD1 Fuel Inj.	SE Series II
1	**Bonnet**		BCP625	BCP625	BLP13
	Hinge		ACP1131	ACP1131	ACP1131
	Striker		BRC40	BRC40	BRC40
	Strut		BRC8756	BRC8756	BRC8568
2	**Grille**		ACP742	ACP742	BRC8165
3	**Front b/bar**		BRC3969	BRC6667	BRC9005
					BRC8810
	End	RH	BRC1732	BRC1732	BRC8806
		LH	BRC1733	BRC1733	BRC8807
	Orider	RH			BRC8820
		LH			BRC8821
	Finisher	RH	BRC6670		BRC9156
		LH	BRC6671		BRC9157
4	**Lower front panel**		JRC1673	JRC1673	CHM314
5	**Front guard**				
	To VIN 341295				
		RH	BLP50	BLP50	BLP50
		LH	BLP51	BLP51	BLP51
	From VIN 341296				
					BLP146
					BLP147
	Inner skirt	RH	ACP1004	ACP1004	ACP1004

Continued

Key	Description		SD1	SD1 Fuel Inj.	SE Series II
		LH	ACP1005	ACP1005	ACP1005
6	**Head lamp assembly**	RH	DRC2593	DRC2593	GLU681
		LH	DRC2594	DRC2594	GLU682
	Globe		JLM9598	JLM9598	JLM9598
7	**Park/flasher assembly**	RH	DRC1769	DRC1769	DRC2496
		LH	DRC1770	DRC1770	DRC2497
	From VIN 298524	RH			AFU2808
		LH			AFU2809
	Lens	RH	AAU2094	AAU2094	AEU1884
		LH	AAU2093	AAU2093	AEU1883
8	**Door shell front**	RH	BLP200	BLP200	BLP200
		LH	BLP201	BLP201	BLP201
	Door skin front	RH	ACP630	ACP630	ACP630
		LH	ACP631	ACP631	ACP631
	Door hinge front upper	RH	DZA420	DZA420	DZA420
		LH	DZA421	DZA421	DZA421
	Door hinge front lower RH/LH		RTC2524	RTC2524	RTC2524
9	**Handle door front outer**	RH	BRC9916	BRC9916	BRC9916
		LH	BRC9917	BRC9917	BRC9917
	Handle door front outer From VIN 276051	RH			JRC2158
		LH			JRC2159
	Door striker RH/LH		BRC2085	BRC2085	BRC2085
	Door latch (solenoid)	RH	BRC9006	BRC9006	BRC8888
		LH	BRC9007	BRC9007	BRC8889
	Door latch (solenoid) From VIN 271981	RH			ACP3700
		LH			ACP3701
10	**Door glass front**	RH	BRC5732	BRC7364	BRC7364
		LH	BRC5733	BRC7365	BRC7365
	Regulator glass	RH	BLP1068	BLP1068	BLP1068
		LH	BLP1068	BLP1068	BLP1068
	Link lead regulator		BAU5140	BAU5140	
11	**Moulding protector guard**	RH	N/A	BRC7260	JPC1564
		LH	N/A	BRC7261	JPC1565
	Moulding protector door	RH	N/A	BRC7258	JPC1566
		LH	N/A	BRC7259	JPC1567
12	**Moulding protector door rear**	RH	N/A	BRC7256	JPC1568
		LH	N/A	BRC7257	JPC1569
	Moulding protector guard rear	RH	N/A	N/A N/A	
		LH	N/A	N/A N/A	

Continued

Key	Description		SD1	SD1 Fuel Inj.	SE Series II
13	**Waist mould door front**	RH	BRC4780	BRC4780	BRC4780
		LH	JRC1717	JRC1717	JRC1717
	Waist mould door front From VIN 299141	RH			JRC2898
		LH			JRC2899
14	**Waist mould door rear**	RH	JRC1718	JRC1718	JRC1718
		LH	JRC1719	JRC1719	JRC1719
15	**Door mirror**	RH	BRC5028	JRC1518	JRC3032
		LH	BRC5027	JRC1519	JRC3032
16	**Door assembly rear**	RH	BLP202	BLP202	BLP202
		LH	BLP203	BLP203	BLP203
	Door skin rear	RH	ACP636	ACP636	ACP636
		LH	ACP637	ACP637	ACP637
	Door hinge rear upper	RH	ACP1058	ACP1058	ACP1058
		LH	ACP1059	ACP1059	ACP1059
	Door hinge rear lower RH/LH		RTC2524	RTC2524	RTC2524
17	**Handle door rear**	RH	BRC6392	BRC6392	BRC9918
		LH	BRC6393	BRC6393	BRC9919
	Handle door rear From VIN 276051	RH			JRC2160
		LH			JRC2161
	Door striker RH/LH		BRC2085	BRC2085	BRC2085
	Door lock (solenoid)	RH	BRC9008	BRC9008	JRC1302
		LH	BRC9009	BRC9009	JRC1303
	Door lock solenoid From VIN 271981	RH			JRC1310
		LH			JRC1311
18	**Door glass rear**	RH	BRC5734	BRC7366	BRC7366
		LH	BRC5735	BRC7367	BRC7367
	Door glass regulator	RH	JRC1454	JRC1454	BLP1070
		LH	BLP1068	BLP1068	BLP1071
	Door regulator link harness		BAU5140	BAU5140	
19	**Rear 1/4 panel**	RH	ACP644	ACP644	ACP644
		LH	ACP645	ACP645	ACP645
	Petrol lid flap		ACP678	ACP678	ACP678
20	**Tail gate**		ACP647	ACP647	BLP11
	Struts		BRC8915	BRC8915	BRC8915
	With spoiler				PAM3786
	Lock		JRC1653	JRC1653	JRC1653
	From VIN 271980				BLP1231

Continued

Key	Description		SD1	SD1 Fuel Inj.	SE Series II
21	**Tail lamp**	RH	DRC2091	DRC2091	DRC2091
		LH	DRC2092	DRC2092	DRC2092
	NO. plate lamp		DRC276	DRC276	DRC276
23	**Rear b/bar**		BRC1730	BRC6682	BRC8800
	End	RH	BRC1734	BRC1734	BRC8816
		LH	BRC1735	BRC1735	BRC8817
	Brk	RH	BRC1802	BRC1802	BRC8812
		LH	BRC1803	BRC1803	BRC8812
	Rear bumper rubbing strip			BRC6683	
24	**Lower panel assembly rear**		BLP14	BLP14	BLP14
25	**Roof panel**		ACP620	ACP620	ACP620
	Sunroof			ACP733	ACP733

ROVER 416I



Key	Description		Part #	Model
1	**Bonnet**		R63110-SE7-E00ZZ	
	Hinge	RH	R63410-SD2-010ZZ	
		LH	R63430-SD2-010ZZ	
	Lock		R63510-SD2-A01	
2	**Grille**			
	Upper	RH	R62301-SD2-000	
		LH	R62311-SD2-000	
	Lower		R62302-SD2-000	
3	**Front b/bar**		R62511-SD2-961ZZ	
	'87 SE		R62511-SD2-010	
	Brk	RH	R62512-SD2-010	
		LH	R62513-SD2-010	
	Air dam (spoiler)		R60853-SD2-000	
4	**Front guard**	RH	R61111-SE7-G00ZZ	
		LH	R61161-SE7-G00ZZ	
	Inner skirt	RH	R04641-SD2-G00ZZ	
		LH	R04651-SD2-G00ZZ	
	Front bulkhead assembly (rad support)		R60810-SD2-A00ZZ	'86
			R60810-SD2-A01ZZ	'87

Continued

Key	Description		Part #	Model
5	**Head lamp assembly**	RH	R33100-SE7-E01	
		LH	R33100-SE7-E01	
	Unit rh/lh		R33110-SB0-601	
	Support panel	RH	R04601-SD2-A00ZZ	
		LH	R04611-SD2-A00ZZ	
	Retractable unit	RH	R33200-SD2-003ZZ	
		LH	R33250-SD2-003ZZ	
6	**Flasher lamp**	RH	R33300-SB2-743	
		LH	R33350-SB2-743	
	Side		R34300-SB0-601	
7	**Park lamp assembly**	RH	R33800-SE7-S01	
		LH	R33850-SE7-S01	
8	**Door shell front**	RH	R75110-SE7-A00ZZ	
		LH	R75150-SE7-A00ZZ	
	Skin front	RH	R75111-SE7-A00ZZ	
		LH	R75151-SE7-A00ZZ	
	Door hinge front upper		R75710-SB2-003ZZ	
	Lower		R75720-SB2-003ZZ	
9	**Handle door front**	RH	R75610-SB3-013	
		LH	R75620-SB3-013	
	Door striker rh/lh		R75555-SB2-003	
	Door lock	RH	R75410-SE7-Q01	'86
		RH	R75410-SE7-Q02	'87 VIT
		RH	R75410-SE7-013	'87 SE
		LH	R75450-SE7-Q01	'86
		LH	R75450-SE7-Q02	'87 VIT
		LH	R75450-SE7-013	'87 SE
	Barrel & key	RH	R72145-SE0-023	
		LH	R72146-SE0-013	
10	**Door glass front**	RH	R75350-SE7-000	
		LH	R75360-SE7-000	
	Regulator	RH	R75310-SE7-J01	POWER
		RH	R75310-SE7-003	
		LH	R75320-SE7-J01	POWER
		LH	R75320-SE7-003	
11	**Moulding protector guard**	RH	R75811-SD2-003	'86
		LH	R75816-SD2-003	'86
	Front door	RH	R75810-SE7-003	'86
		LH	R75815-SE7-003	'86
	Rear door	RH	R75813-SE7-003	'86
		LH	R75818-SE7-003	'86
	Guard	RH	R75814-SE7-003	'86
		LH	R75819-SE7-003	'86
	Moulding protector guard	RH	R75811-SD2-013	'87
		LH	R75816-SD2-013	'87

Continued

Key	Description		Part #	Model
	Front door	RH	R75810-SE7-013	'87
		LH	R75815-SE7-013	'87
	Rear door	RH	R75813-SE7-013	'87
		LH	R75818-SE7-013	'87
	Guard	RH	R75814-SE7-013	'87
		LH	R75819-SE7-013	'87
12	**Waist mould door front**	RH	R75800-SE7-003	
		LH	R75805-SE7-003	
	Rear	RH	R76800-SE7-003	
		LH	R76805-SE7-003	
13	**Door mirror**	RH	R88150-SE7-Q12	POWER
		RH	R88150-SE7-Q01	
		LH	R88155-SE7-Q12	POWER
		LH	R88158-SB3-651	
14	**Door shell rear**	RH	R76110-SE7-A00ZZ	
		LH	R76150-SE7-A00ZZ	
	Door skin	RH	R76111-SE7-A00ZZ	
		LH	R76151-SE7-A00ZZ	
	Door hinge upper		R76720-SE7-003ZZ	
	Lower		R76740-SE7-003ZZ	
15	**Handle door rear**	RH	R76610-SB4-003	'86
		LH	R76620-SB4-003	'86
		RH	R76610-SB4-013	'87
		LH	R76620-SB4-013	'87
	Door striker		R75555-SB2-003	
	Door lock	RH	R76410-SE7-A01	'86
		LH	R76450-SE7-A01	'86
		RH	R76410-SE7-A02	'87 VIT
			R76410-SE7-013	'87 SE
		LH	R76450-SE7-A02	'87 VIT
			R76450-SE7-013	'87 SE
16	**Door glass rear**	RH	R76350-SE7-000	
		LH	R76360-SE7-000	
17	**1/4 glass rear**	RH	R76255-SE7-000	
		LH	R76275-SE7-000	
18	**Rear 1/4 panel**	RH	R04731-SE7-A00ZZ	
		LH	R04741-SE7-A00ZZ	
	Lid petrol flap		R70490-SD2-000ZZ	
19	**Tail gate**		R85210-SE7-Q01ZZ	'86
			R85210-SE7-X02ZZ	'87

Continued

Key	Description		Part #	Model
21	**Tail lamp**	RH	R33500-SE7-S01	
		LH	R33550-SE7-S01	
	Lens	RH	R33501-SD2-003	
		LH	R33551-SD2-003	
	NO. plate lamp		R34100-SB2-741	
22	**Rear b/bar**		R84111-SE7-Q00ZZ	'86 & VIT
			R84111-SE7-E10	'87 SE
	Brk	RH	R84120-SD2-000	
		LH	R84125-SD2-000	
23	**Panel rear**		R80310-SD2-Q00ZZ	
24	**Roof panel**		R70110-SE7-940ZZ	
			R70110-SE7-970ZZ	SUN ROOF